

Skitter TV



TV USER GUIDE

Discover **fun** and convenient viewing
inside your TV



Southeast Nebraska
COMMUNICATIONS

People • Service • Quality



release 6.2.3

THIS PAGE INTENTIONALLY LEFT BLANK

Contents

Contents	i
Introduction	iii
1. Initial Startup.....	1
Log In.....	1
2. Basic TV Controls.....	2
Change the Channel	2
View Current Channel Information	2
Set Favorites.....	3
View the Channel Guide.....	3
Record a Program or Series.....	4
Record a Program Once.....	4
Record a Series	5
Autotune	6
Search Autotunes	7
Search for programs.....	8
Quick Search.....	8
Advanced Search	8
Access Menus.....	9
Get Help	10
Log Out.....	10
3. Optional Menu Features	11
Weather	11
Alerts.....	11
4. My DVR.....	12
Set a Manual Recording	12
View a Recorded Program.....	13
View Recorded Program Folders.....	14
Whole Home Resume.....	15
Remove or Stop Recordings	16
Manage My DVR.....	17
Select Default DVR Settings.....	17
Select Recording Priorities.....	18
5. "My Services" Options	19
Telephony.....	19
6. Account Services	20
Access the Account Menu	20
Change Password	21
Activate PIN Protection	21
Set Purchase PIN	21
Set Rating PIN	22
Create a User.....	23
Set Parental Controls (Locks)	25
Lock user out of TV for a set time.....	25
Lock User Out of a Program/Channel.....	26
Lock User out of TV Indefinitely	26
Manage Subscriptions	27
View Purchased Subscriptions.....	27
Manage User Actions	28
Set Autologin.....	29
View Subscriber Details.....	29
View Billing Activity	30
7. Set Preferences	31

Favorite Channels.....	31
Menu Language.....	32
Channel Settings.....	32
Appearance	33
Set-Top Box Setup	33
Index	34
Remote Control Functions	35
Technical Support.....	37

Introduction

The set-top box is your gateway to the Full-Service Content Delivery Network (fs|cdn®) interactive television service including

Favorite Channels

DVR

Parental Locks

Caller ID alert

This manual is your guide to accessing these services through the remote control unit.

Depending on optional fs|cdn® services available through your service provider, the following additional sections may also be applicable:

My DVR. Applies to set top boxes equipped with hard drives.

THIS PAGE INTENTIONALLY LEFT BLANK

1. Initial Startup

When you connect power to your set-top box *for the first time*, you'll configure the set-top box and log in to fs|cdn.

IMPORTANT: *Do not disconnect power* to the set-top box until Startup is complete. This will take up to 10 minutes. During this time the set-top box will shut down and start up again, lights may flash or blink, and messages will appear on your TV screen.

Startup is complete when the Welcome screen on your TV screen prompts you for your password (see "Log In" on page 1).

Follow the instructions below to set up your system.

Log In

Use number buttons on the remote control to enter your password




- 1 To log in as a user other than the one displayed, press OK to select a different name.
 -  Be sure to use the *manager user* name and password when you sign in for the first time.
- 2 Enter the numeric password for the selected user (using the number keys). Press OK.

The default password is 1 2 3 4.

2. Basic TV Controls

You can control all services from the remote control.

Change the Channel




Using **Number** buttons, enter the channel number.
or

On the **CH (Channel)** buttons, scroll up or down one channel at a time.

View Current Channel Information

Press **INFO** to see a description of the program you're watching.



Set Favorites

When you set Favorite channels, you create a separate program guide just for the channels you watch the most—your Favorites!

- Press **GUIDE** twice to see My Channels program guide.
- Use Δ and ∇ buttons to select a channel you want to add to your Favorites program guide.
- Press the **INFO** button to see program information.



With 'Add to Favorites' selected, press **OK** on the remote control.

 After you set up Favorite channels, press **GUIDE** three times to see the Favorites program guide.

View the Channel Guide



Press **GUIDE** once or twice to see the Channel Guides.

My Channels (channels you subscribe to currently)

Favorites (channels you've set as favorites). Refer to Set Favorites above to set up Favorite channels

The **Help Bar** (below the guide) provides a key to the remote control buttons that navigate through channels and program times.*

Buttons	Function
Arrows (\triangleleft \triangleright Δ ∇)	Scroll through channels and times
Pg Up/Down (\blacktriangle \blacktriangledown)	Jump to previous/next block of channels
Pg Back/Fwd (\blacktriangleleft \blacktriangleright)	Jump to previous/next times
Rewind/FastFwd (\ll \gg)	Jump to previous/next day

* **Help Bar** appears only if activated. Refer to "Appearance" on page 33 for more information. In the Help Bar, "mine" denotes the **Favorites** guide.

Press **EXIT** to close the channel guide.

The Guide window times out after a period of inactivity.

My Channels				5:04 PM
PROGRAM DESCRIPTION	Friends			017 TBS
	6:00 PM - 6:30 PM TVPG Sitcom The One Where Rachel Finds Out. On her birthday, Rachel learns Ross is in love with her.			
	Thu 05/6	5:00PM	5:30PM	6:00PM
	013 FX	In Her Shoes		▶
	017 TBS	The King of ...	The King of ...	Friends
	069 Spike	Star Trek: Voyager		CSI: Crime ... ▶
	500 HDNET	HDNet Fights	Nothing b...	Dan Rathe... ▶
	151 VOOM	◀Th...	The Pursuit of Happyness ▶	

The Channel Guide shows programming and a description of the selected program.

Record a Program or Series

The **Recorded Programs** feature lets you record programming to watch later. Use [My DVR](#) to view recorded programs.

Press **GUIDE** to see your programs or Favorites.

Use the arrow buttons to select the program you wish to record, and then press **OK** to see program information.

From the Program Information window, you can set the program to be recorded—just one time, or several times if it's a series. In this section:

- Record a Program Once
- Record a Series
- Set a Manual Recording

Record a Program Once

Either record a program you are currently watching by pressing the 'Record' button on the remote, **or** select a program in the channel guide and press the 'Record' button on the remote.



To record the selected program only, select **Record** and press **OK**.

 To record a program you're already watching, press the **Record** button on the remote control.

WED 8/11	8:30 PM	9:00 PM	9:30 PM
507 USAHD	◀NCIS	NCIS	◉
508 GEOHD	◀Outlaw Bikers	Locked Up Abroad	

After you set the recording ...


In the Channel Guide, a Record icon indicates that the program is set to record.

Record a Series

If you selected a series, you can record several episodes.



Press **▷** to select **Record series** and then press **OK**.
The *Settings* screen displays.



Use arrow buttons (**◀ ▶ △ ▽**) to navigate, and press **OK** to select options you want to use for recording the series:

Start offset—Number of minutes to record before the program is scheduled to start

End offset—Number of minutes to continue recording after program is scheduled to end

Keep at least—Number of episodes to store


Record episodes—Record only Ribbon episodes, or new episodes and reruns

 Once you schedule a program to Record, you can watch real-time TV—or even schedule another program to Record—without interrupting the recording process.

To set DVR defaults, select **Guide > My DVR > Default DVR Settings** (see page 17).


Select **Record series** and press **OK**.

Press **Exit** to return to regular viewing mode.



After you set the recording ...

In the Channel Guide, a Record icon indicates that the series is set to record.




Autotune

Use the remote control to set your TV to tune to a later program automatically.

Press **GUIDE** to see the Channel Guide.

Press **▷** as many times as needed to see later programming.



Highlight the program you want your TV to tune to later, then press **OK**.



Press **▷** to select **Autotune**, then press **OK**. A message will then appear letting you know that the Autotune has been scheduled.

Any subsequent instances of programming scheduled for Autotune in that time slot will override your original scheduling.



In the Channel Guide, a clock icon indicates that the program is selected for Autotune.




To cancel an Autotune selection, navigate to the program, press **OK**, select **Cancel Autotune**, and press **OK** again.




Search Autotunes

To search Autotunes, select **Search Guide** from the Main Menu.



Select **Autotunes**.



A list of all programming scheduled for Autotune will then appear. Select the program you wish to view details and options for.



The following options are available within Autotune:

- **Record.** Records the Autotune instance only.
- **Record Series-like.** Provides date and time options (including recurrent/repetitive scheduling) for the recording of programming on the selected channel.
- **Cancel Autotune.** Cancels this particular scheduling of Autotune.
- **Add to Favorites.** Places this programming on a list for easy retrieval at a later time.
- **View Channel.** Displays current programming for the selected channel.


Search for programs

Search for specific programming in the Channel Guide.

Press **MENU** to access the Main Menu.




Press ∇ to select **Search**, and then press **OK**.



Quick Search


To search for a category of programming (such as Movies, Sports, or Series) press ∇ to make your selection and press **OK**.



View the **Search Results** of upcoming programs for the category you selected.

Use arrow buttons to select an individual program and see its description at the top of the window.

Press **OK** to see the options.



Advanced Search

Advanced Search lets you find specific programming using search filters—such as program title, channel, or day.

Press ∇ to highlight **Advanced**, then press **OK**.



Press arrow buttons to select one or more categories: **Genre, Type, Channel, Title, Day, From** (start time), **To** (end time).

 Press OK to scroll through options in the fields on this screen.


When you've entered the Search criteria, select **Search** in the Search Channel Guide window and press OK.



If you search by **Title**, select the **ABC** button to access the pop-up keyboard.

Spell the program title using arrow buttons to select the letters; press OK after each letter. When you're done, select the check mark and press OK. (Partial spelling is okay.)

 If Cell-phone like text entry is enabled, you may enter text by pressing number keys on the remote.



After you select **Search** and press OK, you'll see the **Search Results** in a list.

To see a program description, press arrow buttons (Δ ∇) to select the program from the list.

Press OK on any selected program to see the available options.

Access Menus

The **Main Menu** is the gateway to most features.

On the remote control, press arrow buttons (Δ ∇ \triangleleft \triangleright) to select the feature you want, and then press **OK**.

- Press **MENU** to access the Main Menu.
- Press the **blue button** to return to the previous menu.
- Press **Exit** to clear all menus from the screen.


Get Help

Help shows instructions for using the remote control and fs|cdn features.



You can get help in several ways:

- Starting at the Main Menu, select **Settings** [+ok] and then **Help** [+ok]
- Select **Help** in the Help Bar at the bottom of the screen
- Press the green button on the remote control



In the Help Contents, press ∇ or Δ to select a topic, then press **OK**.

Log Out

Normally you'll remain logged in to the set-top box, and simply turn off your TV when you're not watching. However, to log in as a different user, you must first log out.




Press **MENU** to access the Main Menu.

Press ∇ to select **Logout** and press **OK**.

The TV will display the user login screen, allowing you to log in again as the same or different user.

3. Optional Menu Features

Along with standard features, the **Main Menu** lists optional features you can purchase from your service provider.



Press **MENU** to access the Main Menu.

Press ∇ to select the feature you want, then press **OK**.

Features described below are:

- Weather
- Alerts

Weather

Select **Weather** from the Main Menu to display the 6-day forecast for available locations.



Press \triangleright to view alternate locations.

Alerts

Alerts lets you activate or deactivate on-screen notification for Telephony (Caller ID), Chat, and Message services, if you are a subscriber.



Press ∇ to select a service. Press **OK** to deactivate/activate the service.

A check mark indicates service is activated.


Select **OK** and press **OK**.

4. My DVR

The Recorded Programs feature lets you record programming for repeated viewing or viewing at a later time. Use My DVR to view the programming you record.

Set a Manual Recording

Manual recordings let you specify a specific time, channel, and/or date to record without using the channel guide. For example, you could record one channel for an entire evening.



In the Main Menu, select My DVR and then **Set Manual Recording**.



Press buttons (◀ ▶ △ ▽) to select up or down arrows at each field, then press ok to scroll to the setting you want:

Channel

From/To—Start/end times

Repeat—How often to record at these settings, such as Just Once, Weekdays only, Daily

Period start—Date to start recording

 Press **⏪** to backspace your entries. For example, to change 9:30 to 9:00, press **⏪** twice and then type **00**.



1. To name this settings group, click the **Name** tab.
2. In the pop-up keyboard, press arrow buttons to select letters. Press ok after each letter to spell the name, and then select the check mark or OK.
 -  If you don't select a name, the system will assign one. You will see it when you check recording schedules at My DVR > Scheduled.
3. On the Set Manual Recording window, select **Set** and then press OK. Click OK in the confirmation window.
4. To view a list of programs you've scheduled, select My DVR > Scheduled.

View a Recorded Program




In the Main Menu, select **My DVR**, and then press OK.



In the My DVR menu, press ∇ to scroll down to the item you want, then press OK. These menu options let you view recorded programming:

- Recorded**—All programs recorded
- Scheduled**—All programs scheduled to be recorded
- Series Folders**—Series episodes recorded
- Manual Recordings**—Manual recordings
- All...**—All recordings for user logged in
- All users' recordings**—All recordings made or scheduled by all users on this set-top box

 For information about different types of recording, see "Record a Program or Series" starting on page 4.



In the list that appears, press ∇ or Δ to select a program and press OK. Information at the top of the window describes the selected program.


Symbols show the status of each listing:

-  Completed successfully
-  Unsuccessful
-  In progress
-  Scheduled
-  Interrupted




Select **Start** to start the program at the beginning, or select **Resume** to continue watching a program from where you stopped. Press **OK**.

Navigate the program with Play, Stop, Pause, Rewind, or Fast Fwd.



View Recorded Program Folders

To view a recorded program folder within fs|cdn, select **Series** from the My DVR menu.



Select the series you wish to view by highlighting it and pressing **OK**.




The list of available episodes for that series will then appear.

indicates that the episode has not aired yet and has been scheduled for recording.

indicates that the episode has already aired and is available for viewing.

indicates that the episode is airing currently.

Select an episode with either or adjacent to it. Press **OK**.




Highlight **Start** and press **OK** for the selected episode to play from the beginning.

Whole Home Resume

The Home House Resume feature allows viewers with multiple television sets to pause recorded programming on one set and resume it on any other household set without missing any of the content. The programming will automatically restart from the point at which it was paused.



On the television you will no longer be viewing, press **Pause (II)** to pause the programming.



To resume the program on another television set, locate the program, then highlight it and press **OK**.

The program will then commence from exactly the point at which it was paused on the other television.

Remove or Stop Recordings



In the Main Menu, select **My DVR > Recorded**, select to view recordings listed by date or by title, and press OK.

From the list of programs, select the program you want to remove and press OK.



Select the option you want and then press OK:

Remove—Erase the selected program from the Recorded list

Remove all—Erase all programs in the Recorded list

Interrupt series—Keep the series already recorded, but stop recording future episodes

The window includes other controls for the selected program:

Start—Play the recording

Cancel—Discontinue this action

Resume—Continue to play the program if it has already been started

Settings—Change recording preferences for the program (for more information about recording preferences, see “Select Default DVR Settings” on page 17.)


Manage My DVR

Managing your recordings will optimize My DVR performance when you record programs for later viewing. This section describes how to set these controls:

- Default DVR Settings
- Recording Priorities

Select Default DVR Settings

Use this option to pre-set your recording preferences for different types of programs such as series, movies, and sports.



In the Main Menu, select **My DVR > Default DVR Settings**.



Use the arrow buttons (◀ ▶ △ ▽) to select up or down arrows at each field, then press ok to scroll to the setting you want (settings vary depending on the Type):

Type—Type of recording, such as Series Recordings, Single series episodes, Movies, Shows, Sports, Manual Recordings

Start offset—Number of minutes to start recording before the program is scheduled to start

End offset—Number of minutes to continue recording after program is scheduled to end

Keep until—How long to store recorded programs

Keep at least—Number of episodes to store


Record episodes—Record only new episodes, or new episodes and reruns

Select **Apply** and press ok.


Manage My DVR

Select Recording Priorities

If the number of recordings scheduled at one time is more than allowed, use this option to choose which program to record. This is useful if you have scheduled a series, which records repeatedly and may conflict with other programs you schedule.



In the Main Menu, select **My DVR > Priorities**.



Programs scheduled for recording display in a list. The higher the program in the list, the higher its priority:

To move a program higher or lower in the priority list, follow these steps:

For higher priority—Select the program, then press OK

For lower priority—Select the program, then press the Info/red button

5. "My Services" Options

My Services are optional services you can purchase from your service provider.




Find available service options on the Main Menu or by selecting **My Services**.

Some services are described below:

- Vudu downloads
- Telephony
- Messages
- Chat

Telephony

Telephony service displays a Caller ID pop-up alert at the top of your TV screen when you have an incoming phone call. The alert shows phone numbers for the receiver and caller.



When the call alert appears, simply wait for it to time out, or press OK on the remote control to close the alert.

To activate Caller ID, refer to "Alerts" on page 11.

6. Account Services


Account setup may include some or all of these procedures, depending on the services you've ordered.

Topics in this section:

- Access the Account Menu *(page 20)*
- Change Password *(page 21)*
- Activate PIN Protection *(page 21)*
- Create a User *(page 23)*
- Set Parental Controls (Locks) *(page 25)*
- Purchase Subscription Packages *(page **Error!** **Bookmark not defined.**)*
- Manage subscriptions *(page 27)*
- Manage User Actions *(page 28)*
- Set Autologin *(page 29)*
- View Subscriber Details *(page 29)*
- View Billing Activity *(page 30)*

Access the Account Menu


To set up or change your services, first access the **Account** menu.



Press **MENU** to access the Main Menu.

Press **▽** to select **Settings** and press **OK**.

Select **Account** and press **OK**.



From the Account menu, select the activity you want.

Some account activities are described in this section:

- Change Password *(page 21)*
- Purchase PIN *(page 21)*
- Rating PIN *(page 22)*
- Manage Users *(page 23 and 28)*
- My Own Subscriptions *(page 27)*

Change Password

These instructions will change the current user's password. To change another user's password, refer to "Manage User Actions" on page 28.

Access the **Account** menu (page 20) and select **Change Password**.

Complete the fields:

Frame – Use number buttons to enter old password.

New – Use number buttons to enter new password.

Confirm – Enter the password numbers again.

Press ∇ to select **OK**. Press **ok**.

Activate PIN Protection

fs|cdn features two types of optional personal identification numbers (PINs): **Purchase PIN** allows secure purchase of subscriptions or services, and **Rating PIN** allows parental controls.

Set Purchase PIN

When activated, a Purchase PIN is required to purchase subscriptions.

Access the **Account** menu (page 20) and select **Purchase PIN**.

Complete the fields:

New PIN – Use number buttons to enter 4-digit PIN.

Confirm new PIN – Enter the PIN again.

Password – Enter your 4-digit numeric password.

Enable PIN Protection – Press **ok** to select **Yes** or **No**. (Will appear only if PIN Protection is activated.)

Click **Apply** and press **ok**.

Set Rating PIN

A **Rating PIN** allows a user to view programming with a higher rating than the rating specified when the user was created (see “Create a User” on page 23). The *manager user* may set Rating PINs.

Access the **Account** menu (page 20) and select **Rating PIN**.

Complete the fields:

New PIN – Use number buttons to enter the 4-digit PIN.

Confirm new PIN – Enter PIN again.

Password – Enter your 4-digit numeric password.

Enable PIN Protection – Press ok to select Yes or No. (Will appear only if PIN protection is activated.)

If No, then this user cannot view programming with a higher rating under any circumstances.

PIN Protected Rating – Press OK to select the highest rating user can view without a Rating PIN.

Select **Apply** and press ok.

Example:

John is a 13-year-old user specified with a **TV-14** rating. His parents also assigned John a PIN-protected rating of **R**.

The following rules apply to John:

PIN-Protection enabled (option 'Yes')	<ul style="list-style-type: none"> ✓ May view programming as high as TV-14 without PIN ✓ May view R with PIN ✓ May not ever view higher than R
PIN-Protection disabled (option 'No')	<ul style="list-style-type: none"> ✓ May view as high as TV-14 only

Create a User

The **Manager User** for a subscriber account can create additional users.



Access the **Account** menu (page 20) and select **Manage Users**. Select **Create New** and press ok.

 If you don't see the **Create New** option, it's because your account already has the maximum number of users. Contact Customer Service to add more users.



With **ABC** selected, press ok.



In the pop-up keyboard, press arrow buttons (< > &triangleup; ▿) to select letters. Press ok after each letter to spell the new username.

Select the check mark and press ok.

Ratings:

ALL - all programs
 TVMA - mature audience only
 R - restricted
 TV14 - parents strongly cautioned
 TVPG - parental guidance suggested
 TVG - general audience
 TVY7 - directed to older children
 TVY - approved for all children

Complete the remaining fields:

Password	Press number buttons on the remote to enter a numeric password of your choice. [If you make a mistake, press Pg Back to erase. Refer to your remote control diagram at the beginning.]
Confirm	Enter the password numbers again.
Rating	Press OK to scroll through ratings. Stop at the highest rating level you want this user to view. Users will need a Rating PIN to view programming higher than the rating you specify here. Refer to page 22 for details.
Sp.Limit	Press number buttons to enter amount this user may spend per billing period (for VoD, PPV, etc.).
Can(not) Subscribe	Press OK to toggle between Can and Cannot Subscribe . <i>Can Subscribe means this user will be able to add subscription services.</i>

Select **OK** and press **OK** to save settings.

Set Parental Controls (Locks)


The *manager* user can control user viewing in several ways:

Lock user out of TV for a set time (*page 25*)

Lock user out of a program / channel (*page 26*)

Lock user out of TV indefinitely (*page 26*)

For all Lock settings, access the **Account** menu (*page 20*) and select **Manage Users**.



For all Lock settings, begin by selecting Manage Users, and then select the user you wish to control. Press ok.



Select **Locks** and press ok.

Continue with the instructions below for the action you want (lock user out of program, out of channel, or out of TV).

Lock user out of TV for a set time



Complete the **From**, **Duration**, and **Daily** fields by pressing ok to scroll through options.

With the fields set, select **Lock** and press ok.

Lock User Out of a Program/Channel



Select the user account as described above.

Select **Channel Locks** and press ok.



Select the program to lock, or any program in the channel to lock, and press ok.



Select **Lock Program** or **Lock Channel**, and press ok.

To unlock, repeat these steps, except select **Unlock**.



The channel guide will show a padlock symbol to identify the program or channel as locked.

Lock User out of TV Indefinitely



Select the user account as described on page 25.

Select **Lock Now** and press ok. This user will be blocked from logging in.

To unlock the user, repeat these steps, except select **Unlock Now**.

Manage Subscriptions

To purchase a subscription, refer to ***“Error! Reference source not found.”*** on page **Error! Bookmark not defined.**, or contact Customer Service.

View Purchased Subscriptions

View subscription bundles already purchased for the user logged in.



My Own Subscriptions - thomas		4:28 PM
Subscription	Package	
Conklin Basic	Conklin-TV	
VoD	Conklin-TV	
MPEG2	Conklin-TV	

Access the **Account** menu (page 20) and select **My Own Subscriptions**.

Select a subscription and press OK.




Details - Conklin Basic		4:28 PM
Description: Basic Local Channels		
Products: WSB, FNC, PCHTV, HDNMOV, KTPX, NFL, FX, WAGA, HD2, fscdn, HDNET, M4HD, CMGS, G4		

View the description of the subscription you chose above.

Manage User Actions

From the main user account you can create or modify settings for additional users in the account.

User settings include subscriptions, parental locks, password, and Autologin.



Access the **Account** menu (page 20) and select **Manage Users**.

Select the user name and press **OK**.

Changes you make in the next screens will be for the user you select here.



Select a **User Action** category to view or modify. Press **OK**.

The manager user may take these actions for the selected user:

Avail. Sub.	Follow steps in " Error! Reference source not found. Error! Reference source not found. " on page Error! Bookmark not defined.
My Own Sub.	View current subscriptions for the selected user.
Locks	Activate/deactivate parental control for programs or channels. Follow steps in "Set parental control (Locks)" on page 25.
Modify	View or change user info including password and rating.
Activity	View billing activity.
Autologin	Set the user login so it doesn't require a password.
Delete	Delete selected user. (Select Yes or No .)
Cancel	Discontinue

Set Autologin

When you set Autologin, the login procedure becomes disabled and no password is required.



Access the **Account** menu (page 20) and select **Autologin**.

Press ∇ to select **Set Autologin User** and press ok.

Use the same steps to turn off Autologin.

 Other users will be able to access your account when Autologin is enabled.

View Subscriber Details

View subscriber settings for the user who is currently logged on.

Details - 'thomas'		5:53 PM
User ID	thomas_41	
Manager	yes	
Subscriber Name	Magnum Thomas	
Rating	ALL	
Can Subscribe	yes	
Spending Limit	unlimited	
Contract End Date	10/27/2016	

Access the **Account** menu (page 20) and select **Details**.

To change settings, please contact Customer Service.

View Billing Activity

View current billing activity for a specific user or for all of the users in an account.

Activity		5:54 PM	
01-01-2008 - 31-01-2008	thomas	All Users	
Pay Per View	\$0.00	\$0.00	
Subscriptions	\$12.00	\$12.00	
Other Services	\$0.00	\$0.00	
Telephony	\$0.00	\$0.00	
Fees	\$10.00	\$10.00	
TOTAL	\$22.00	\$22.00	

Access the **Account** menu (page 20) and select **Activity**.

If you have questions about your bill, please contact Customer Service.

Activity Details - Subscriptions		1:46 PM	
User: Teri			
1. TUE 1/1 12:13 AM, News, \$0.00 (SP Subscription Membership payment due)			
2. TUE 1/1 12:09 AM, Basic, \$0.00 (SP Subscription Membership payment due)			

To view details about a particular item, select the item and press OK.

7. Set Preferences

Preferences are customized settings you can make for your fs|cdn system to control:

- Favorite channels
- Menu language
- Channel settings
- Appearance of menus and windows
- Set-top box setup



Press **MENU** to access the Main Menu.

Press **▽** to select **Settings**, and then press **OK**.

The Settings menu displays.



*To go to Preferences, select **Settings** in the Main Menu*

Press **▽** to select **Preferences**, and then press **OK**.

In the Preferences menu, select from the options and press **OK**:

Favorite Channels—Make it easy to see the channels you watch most (*see page 31*)

Menu Language—Change the language in on-screen menus and windows (*see page 32*)

Channel Settings—Select an alternate language for broadcasts (*see page 32*)

Appearance—Select a different color or design for menus and windows (*see page 33*)

Set-top box Setup—Change advanced set-top box settings (*see page 33*)

Favorite Channels

The channels you set up as **Favorites** will appear in a separate program guide. This way, you can avoid scrolling through dozens of channels to find the ones you watch most.



Select **Menu > Settings > Preferences > Favorite Channels**.

Click a channel in the left column to add it to your Favorites list.

Click a channel in the right column to remove it from your Favorites.

 Add as many Favorite channels as you like—there is no limit.

Menu Language

Menu Language controls the language for on-screen menus and windows.




Select **Menu > Settings > Preferences > Menu Language**.

Press ∇ to select the language you want, and press OK.

 Language order remains the same.

Channel Settings

Channel Settings control broadcast language and audio format.




Select **Menu > Settings > Preferences > Channel Settings**.

Press ∇ to select the setting you want to change, and press OK:

- Language—Select a different language for broadcasts, when available
- Audio—Change the audio format options

Appearance

Appearance controls the on-screen format for menus and windows.



Menu Help Bar



Channel Guide Help Bar



Select **Menu > Settings > Preferences > Appearance**. Press arrow buttons to move through the options. Press **OK** to make a selection.

Transparency

Transparent—Current program shows through on-screen windows.

Opaque—On-screen windows are opaque.

Color Schemes

View samples on next page.

Font Size

Type size in on-screen windows.

Font Weight

Bold or plain.

GUI Type

Ribbon or Frame.

Help Bar (at left) When “on,” keys to shortcut buttons appear below Channel Guide and menus.

Thumbnail Video When “on,” a small video image of your current program shows while you view the Channel Guide.

With your selections made, arrow to **Apply** and press **OK**.

Set-Top Box Setup

Set-top box Setup controls advanced settings for your set-top box.



Select **Menu > Settings > Preferences > Set-top box Setup**.

Use the arrows to select the settings you want:

Digital Audio Output—Off or on

Component Output—SD (standard definition) or HD (high definition)

Output Aspect Ratio—AUTO (automatic), 4/3, or 16/9

With your selections made, arrow to **Apply** and press **OK**.


 Changing set-top box settings may cause the set-top box to reboot.

Index


- Account menu, 20
- account services, setup, 20
- alerts, activate, 11
- appearance, choosing, 33
- audio format, 32
- Autologin, 29
- Autotune, 6
- billing activity, 30
- Caller ID, 19
- change password, 21
 - user's, 28
- channel
 - changing, 2
 - locks, 25
 - view information for, 2
- channel guide
 - quick search, 8
 - search for programs in, 2, 8
 - viewing, 3
- channel settings, selecting, 32
- color schemes, 33
- DVR, 12
 - manage, 17
 - priorities, 18
 - settings, 17
- exit fs|cdn, 10
- Favorite channels, setting, 31
- font, setting, 33
- genre
 - search for program by, 9
- guide. *See* channel guide.
- Help Bar, 3
 - turning on, 33
- language
 - for broadcasts, 32
 - for menus and windows, 32
- language for menus, 33
- lock user
 - out of a program, 26
 - out of TV, 25
 - out of TV indefinitely, 26
- locks, program/channel, 25
- log in, 1
- log out, 10
- Main Menu, accessing, 9
- manager user actions, 28
- manual recording, 12
- menu
 - accessing, 9
 - choosing appearance, 33
- My DVR, 12
- My Services. *See* services.
- parental control, 25
- password
 - change, 21
 - changing user's, 28
 - default, 1
- PIN
 - activating, 21
 - protection, setting, 22
 - purchase, setting, 21
 - rating, setting, 22
- preferences, setting, 31
- programs
 - quick search, 8
 - search for, 8
- purchase PIN, 21
- quick search, 8
- rating PIN, setting, 22
- ratings
 - assign level to user, 24
 - definitions, 24
 - setting a PIN for, 22
- recorded programs
 - recording a program, 12
 - remove, 16
 - resume, 14
 - viewing, 13
- Recorded Programs feature, 4
- recording
 - a program once, 4
 - default settings, 18
 - manual, 12
 - priorities, 18
 - series episodes, 5
- search
 - for programs, 8
- series
 - interrupt, 16
 - recording, 5
- services
 - activate alerts, 11
 - setup, 20
 - telephony, 19
- set-top box
 - exiting, 10
 - setup, 33
- spend limit, 24
- startup, 1
- subscribe, assign privilege to user, 24
- subscriber details, 29
- subscriptions
 - view purchased, 27
- technical support, 37
- telephony service, 19
- thumbnail, turning on, 33
- title
 - search for program by, 9
- TV
 - basic controls, 2
- user
 - actions, manage, 28
 - create new, 23
 - modify settings for, 28
 - set program/channel locks for, 25
- weather, 11

Remote Control Functions

Universal Remote (model UR5L-9000L-IP)



Amino Advanced Remote (WILLOW)



SHORTCUT BUTTONS			
 CURRENT PROGRAM INFO	 HELP	 CHANNEL GUIDE	 PREVIOUS MENU
USER LOGIN SCREEN KEYS			
 BACKSPACE	 NEXT/ PREVIOUS USER		

Technical Support

This user manual is intended for use by Owner personnel and fs|cdn end users.

If you have questions or problems please contact Southeast Nebraska Communications:

phone: **402-245-4451**

afterhours phone: **402-245-5999**

e-mail: snc@sentco.net

website: <http://www.sentco.net/>

Information included in this document is correct at time of release.

© 2011 Conklin Corporation, all rights reserved.

Printed in the USA.

fs|cdn and the Intelligent Personal|TV logo are registered trademarks of Conklin Corporation.

All other trademarks are the properties of their respective owners.

UM-CDNSTBC-6.2.3